



HOLSTEIN DYSTOCIA SIMULATOR

The VSI Holstein Dystocia Simulator is a high-fidelity training tool trusted by veterinary educators worldwide. Designed with accuracy and functionality in mind, the VSI Holstein Dystocia Simulator is realistic in both size and conformation. The calf is equipped with a steel, articulated skeleton which allows it to be placed in a variety of positions allowing students to gain the confidence needed to perform dystocia scenarios in a live setting – increasing clinical proficiency and helping to protect both the cow and calf.

The Holstein Dystocia Simulator includes a functional milk tank which can be used to perform the California Milk Test (CMT) through the introduction of mastitic milk into any of the milk tank quadrants. Both the Bovine Venipuncture/Epidural Tail and the Bovine Uterus Set with Holstein Palpation Panel Assembly, are compatible with the Holstein Dystocia Simulator resulting in a well-rounded, practical training tool and outstanding addition to any bovine clinical skills training program.



DAY ONE SKILLS & PRODUCT BENEFITS

- Able to position the calf in a variety of positions to accommodate for various dystocia simulations
- Udder and milk tank assembly – ability to simulate mastitic milk in various udders
- California Milk Test
- Build student confidence and develop familiarity with calf positioning and palpation
- Matching articulating Holstein Calf included. Metal skeleton allows for appropriate force and for calf to be positioned. 18kg (40lb) birthing calf size

POSSIBLE CALF PROCEDURES

- Passageway for intubation tube
- Rectal palpation
- Durable, flexible and easy to clean skin
- Compatible with the Bovine Venipuncture/Epidural Tail model & TB Caudal Fold Tail
- Compatible with the Bovine Uterus Set with Holstein Palpation Panel Assembly for artificial insemination and reproductive training
- Realistic in size and aesthetically pleasing allowing for better immersion in training scenarios

Holstein Dystocia Simulator 1025528



TECHNICAL SPECIFICATIONS

- Height 1.8m, Length 2.7m, Width 1m
- Steel reinforced fibreglass model, water resistant components for easy cleaning
- Removable hatch for easy access points
- Interchangeable parts for multiple simulations
- Inflatable calf air bed support
- Vinyl uterine bag
- Soft, durable birthing perineum panel
- Flexible removable tail
- Replica pelvis
- Padded fetal extractor, obstetric chain, head snare, landing mat

REPLACEABLE PARTS

- Birthing Perineum Panel
- Teats
- Standard Tail
- Uterine Bag
- Calf

UPGRADABLE PARTS

- Artificial Insemination techniques can be practiced with the purchase of the Holstein Palpation Panel Assembly With Bovine Theriogenology Uterus Set. Students can palpate at 45, 60 & 90 days of pregnancy. Bovine uterus set includes interchangeable ovaries.
- TB Caudal Fold Tail
- Venipuncture/Epidural Tail

IF YOU HAVE ANY QUESTIONS OR NEED SUPPORT, PLEASE SCAN HERE



3B Scientific Group

Headquarters · Ludwig-Erhard-Strasse 20 · 20459 Hamburg · Germany · 3bscientific.com